

THRIVE LED Home Lights

User FAQs

Please go through these FAQs that will help you to properly use and maintain the THRIVE light.

How is THRIVE light charged?

The light can be charged either through solar energy, using a solar panel or through electric energy using a power connection.

How many modes of lighting does the THRIVE light have?

It has three modes of lighting: bed light mode, reading light mode and bright light mode.

How often does the THRIVE light need to be recharged?

A fully charged light is sold to you; it needs to be recharged only after 500 hours in bed light mode, 70 hours in reading light mode and 30 hours in bright light mode.

Can the THRIVE light be used with the charger connected to it?

The electric charger or the solar pin needs to be disconnected from the light before using it.

How many hours does it take to fully charge the THRIVE light using electricity?

It takes 5 to 6 hours to fully charge the light.

How long does it take to fully charge the THRIVE light using the solar panel?

The solar panel needs 10 hours of exposure to sun light, while being connected to the light, to be fully charged.

Is the THRIVE light affected in any way if continuously left charging to either an electric charger or a solar panel?

The light is not harmed in any way if continuously left charging to either an electric charger or a solar panel

Where should the solar panel be fixed?

The solar panel should be fixed at a place where it is best exposed to maximum sun light.

Where should the THRIVE light that uses the solar panel for charging be placed?

The light can be always connected to the solar panel by means of an extended wire and placed at any place within the house.

Should the THRIVE light that uses the solar panel for charging be always connected to the solar panel?

It is advisable to always have the light connected to the solar panel during the day and unplug it for use during night.

How does one know that the battery is low?

The red light indicator comes on when the battery is low and the light shuts down.

Is there any way the user can still use the light after the red light indicator comes on for the first time?

The light can glow in the reading light mode for a further 20 minutes, after the first time the red light indicator comes on and the light shuts down; the light can glow in the bed light mode for a further 10 hours, after the first time the red light indicator comes on and the light shuts down

How often does the battery need to be replaced?

The battery will last for 3 years before needing replacement

What are the specifications of the THRIVE light battery?

It is a very commonly available 6 Volts 4.5 Amps lead acid battery.

Thrive Energy Technologies (P) Ltd.

12-13-333, Street No.10, Tarnaka, Secunderabad - 500 017. Andhra Pradesh, INDIA.

Phone No.: +91 40 40181212, Email: info@thriveenergy.co.in

www.thriveenergy.co.in; website: www.thrive.in

THRIVE LED Home Lights

User FAQs

Please go through these FAQs that will help you to properly use and maintain the THRIVE light.

How can one replace the battery?

The battery can be replaced by sliding open the plate located at the bottom of the light, removing the old battery and replacing a new one.

Can the old battery be exchanged?

The old battery can be exchanged for a new one at no cost if deposited with THRIVE

Is there a specific voltage specification with which the THRIVE light can work?

The light can work on voltages specific to the USA and India. It can also work on very low voltage that exists in village power systems.

What would be the monthly expenditure that one would incur by using one THRIVE light in a household?

If the light is used for 4-5 hours a day, the electric power cost (metered) is around 30 paise a month for charging the light.

Can a water spill over the THRIVE light damage the light?

An accidental water spill cannot damage the light, but if the light is immersed in water for a prolonged period, it can

damage the circuit; the circuit can be repaired at our customer care centre for less than Rs100.

Can the THRIVE light get damaged if dropped?

An accidental drop will not damage the light but an intentional throw can cause damage.

Is the glass that covers that front portion of the light breakable?

The front glass is made of poly carbon and does not break unless banged with a hammer.

What are the various ways in which one can use the THRIVE light?

THRIVE light is designed for use with bicycles, bedside reading, table top reading, as an emergency lamp and as a night camping light.

Where can one get further details on THRIVE?

www.thrive.in provides all details on the organization THRIVE and THRIVE lights.

Thrive Energy Technologies (P) Ltd.

12-13-333, Street No.10, Tarnaka, Secunderabad - 500 017. Andhra Pradesh, INDIA.

Phone No.: +91 40 40181212, Email: info@thriveenergy.co.in

www.thriveenergy.co.in; website: www.thrive.in